

JERRY HARVEY AUDIO IMPRESSION TIP SHEET FOR AUDIOLOGISTS



- 1** JH AUDIO manufactures a full shell earpiece. What we need from our customers is a full shell impression, including the crus of helix, tragus, and anti-tragus.
- 2** The impressions must be made of high-viscosity silicone impression material.
- 3** We prefer and recommend that the ear dams are made of foam.
- 4** It is required that we have an open mouth impression taken to the second bend of the ear canal. To ensure there is no jaw movement while the material is curing, a bite block must be used prior to the injection and throughout the entire process. To accomplish this:
 - A.) Customer's mouth should be wide open when the impression material is injected into the ear.
 - B.) Have the customer keep their mouth open until the impression has completely cured.
- 5** Want to know if your impressions are acceptable before you mail them to us? Text us at **321-320-5189**. Send your name and a few photos of your impressions to get initial approval for them. Final impression approval occurs upon arrival.
- 6** Send impressions to the address below. If you have any questions or comments, please contact us:

Jerry Harvey Audio

Attn: Lab

111 West Jefferson St, Suite 300

Orlando, FL 32801

Phone: 866-485-9111

Fax: 407-814-0018

www.jhaudio.com



**Impression of
1st & 2nd Bend**



Concha Bowl Fully Formed



Defined Helix



**Extra Material Outside
of the ear, above Tragus.**

